



		Spare part number	Spare part number	Colours available
1	Upper hinge		692771	
2	Fixing nut			
3	Fixing leg			
4	Left bottom hinge			
5	Right bottom hinge			
6	PCB		692772	
7	Light cover			
8	Sticker	692773		
9	Control housing	692774		
10	Cover plate	692775		
11	Thermistor Cover		692776	
12	Thermistor			
13	Internal fan	692777		
14	Fan cover	692778		
15	Light housing		692779	
16	LED light			
17	Light cover			
18	Breakfast tray	692780		
19	Door latch plate		692758	
20	Winter lock support			
21	Plate	692782		
22	Bottom cover	692783		
23	Power cord	692784		
24	Condenser fan	692785		
25	Control module			
	<i>Serial Number range</i>			
	<i>ExxxxDWxxxxx</i>			
	<i>Exxx#xDW0026xxxx - Exxx#xDW0042xxxx</i>	691391		
	<i>Exxx#xDW0043xxxx - Exxx#xDW0065xxxx</i>	692821		
26	Air duct	692786		
27	2-way valve			
28	Drip cup	692788		
29	Freezer door	691877		
30	Food retainer	692789		
31	Cover slide out box	692790		
32	Clip shelf large	692791		
33	Shelf	692792		
34	Cabinet door		692793	
35	Deco panel	69233127SP		
36	Door bin	692794		
37	Drawer divider	691878		
38	Drawer guide	691874		
39	Door cover	692795		
40	Drawer bin	692796		
41	Panel retainer	692797		

42	Upper hinge shaft		
43	Silicone blanking cap		
44	Upper hinge shaft	691456	27
45	Upper hinge shaft spring		
46	Handle groove		
	Handle		
47	Handle connecting shaft	692798	
48	Big handle spring		
49	Small handle spring		
50	Door switch	692641	

**Note Identification Label**

With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.

